



## The DDL2 Dental RO System

An under sink filtration unit providing pure R.O. and De ionized water suitable for autoclaves, **Decontamination rooms and DUWLs.**

The DDL2 RO System provides a consistent supply via a separate tap.

Mains water is fed to the DDL2 R.O system, then forced through pre-filters and a semi permeable membrane via a booster pump.

The resulting water is a very pure quality.

Alkaline Earth minerals which cause “furring” are removed. Chlorides/Phosphates & Silicates which cause corrosion are removed.

The DDL2 is supplied with a portable TDS/Micro Siemens test meter to check water quality.



# Technical Data - DDL2 RO

## Dimensions

Plus Storage tanks as required.  
W 33 x D 21 x H 40 cm - Weight 8KG  
Fits conveniently in a cupboard, either upright or on its side

Can be sited on work surface if required

## Power consumption-

Standard 240 v AC mains

Wattage 1 Amp auto shut off when storage tanks are full

## Water Production

Up to 300 litres per day

Water stored in sealed storage tanks for fast dispensing.

## Washer disinfectors

Can be connected to final rinse on washer disinfectors \*

**THE DDL TAC WATER SOFTENER IS NOW AVAILABLE...Ask for details.**

## Accreditations



[See also our Q&A sheet](#)

## Dispensing tap

Separate dispensing tap included.



## Maintenance

Filter change generally required once per year unless high usage requirement or reduced inlet water quality .

This is done by our professional engineers

## Installation

Nationwide service with our professional engineers .

WRAS approved double non return valve on inlet to comply with water regulations

## Quality Assurance Testing

Portable meter left at practice for testing TDS /Micro Siemens water quality.

All our filters are manufactured by a water quality standard member .

\*Check with us for compatibility

Contact details:

[account@dentaldecontamination.net](mailto:account@dentaldecontamination.net)

01253 736355